



Standard



Lattice '83



Deluxe

## Installation Guide

*The*  
**STANDARD**

*The '83*

*The*  
**DELUXE**


PVC + Cedar  
Models



# Standard Kit Installation Guide


## Standard Ingredients

<p>Post Caps</p> 	<p>Braces</p> <p>Corner Braces</p> 	 <p>Small Wall</p> <p>Door</p>
<p>Floor</p> 	<p>Door Brace</p> 	
<p>Posts</p> 	<p>Hardware Pack</p> 	



### House Mount

- 2 Large Walls
- 1 Small Wall
- 1 Door
- 5 - 7' Cedar Posts
- Cedar Post Caps
- Cedar Floor
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace



### Free Standing

- 3 Large Walls
- 1 Small Wall
- 1 Door
- 5 - 7' Cedar Posts
- Cedar Post Caps
- Cedar Floor
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace

**CUSTOM TIP:**  
Doors can be rotated on any side you choose. Our kits are set up for altering doors + walls.

# STANDARD INSTALLATION

## House Mount Single Unit

### Tools Needed:

Drill

Level

(L-Bracket for posts against house)



Choose your posts and pick the best end for the top. Remember to decide how high off the ground you want the kit positioned. Use a block or item to be referenced for height on all posts. We recommend 7".

*Our walls are built with rain caps. These will be the wider boards of the structure built into the top of the wall.*

*This part of the wall will be the top.*

For Posts against the house, you can secure one 1st - PVC can be direct drilled, Some use angle brackets for Cedar and 2-3" screws.



Use the construction screws in your hardware pack and connect a large wall to a cedar post. Make sure the inside of the wall is flush to the post. Repeat for the second large wall.

Next, attach one wall to the house. Always making sure the wall is level. Then, measure one of the walls as reference to use for the space along the back side of the house for house mounting.



Complete the second wall mount. Make sure the distance from the first wall mount is the right size (size of the wall panel) and level. Use a reference point against the wall or mark of with a pen / marker.

Then, install the second wall and make sure it is level.

## STANDARD INSTALLATION



Take the small wall and attach a post to it - again making sure the height from the ground matches the other 2 walls. Add the small wall. Drill the construction screws at an angle for easier use.

Applying the corner braces: Each kit comes with corner braces. Use these at corners to act as added support for the 90 degree angle.



Installing the door: Use the door hardware from the hardware pack and install on the door first. Then install the door. Keep about 1/4" between of each side of the door and the shower kit when securing the door.


Don't forget to install the door brace above the opening for maximum stability!



Getting out:

After the door is installed and the latch is in place, use an extra hole to thread the latch or tie through space of the door.








That's it!  
Just add any finishing touches  
...and water!




For Finishing Touches + Accessories Installation  
See Page 10

# The '83 Kit Installation Guide

## '83 Ingredients

<p>Post Caps</p> 	<p>Braces</p>  <p>Corner Braces</p>	<p>Large Wall Door Large Wall</p> 
<p>Floors</p> 	<p>Door Brace</p> 	
<p>Posts</p> 	<p>Hardware Pack</p> 	



### House Mount '83

- 3 Large Walls
- 1 Door
- 5 - 7' Cedar Posts
- Cedar Post Caps
- 2 Cedar Floors
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace




### Free Standing '83

- 4 Large Walls
- 1 Medium Wall
- 1 Door
- 6 - 7' Cedar Posts
- 3 Cedar Post Caps
- 2 Cedar Floors
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace

**PLEASE NOTE:** '83 DOOR CAN ONLY BE ON SHOWER SIDES WITH A CUSTOM WALL ARRANGEMENT


# THE '83 INSTALLATION

## House Mount Mid-Size Unit



Our walls are built with rain caps. These will be the wider boards of the structure built in to the top of the wall. This part of the wall will be the top.

Attach the posts to the large panel walls. Use a block or item to be referenced for height on all posts. We recommend 7". Use the construction screws provided in the boxes.



Its so easy, you can stop and smell the flowers.

Continue along where the marks are screwing the walls to the posts. This can be done with the assistance of someone.

When finished, bring the wall panel to the area on the house. Make sure the correct distance is accounted for between the walls that are being mounted.



Drill with screws at an angle into the house. Make sure the screws go in at about a 45° angle.

*Note: If you are using posts against the house with stone, please get in touch with us for recommendations for mounting.*


As always....make sure EVERYTHING is level and properly measured for spacing.

# THE '83 INSTALLATION



Do the same for the door and small wall.

When assembling the door, use the door hardware supplied. Keep about 1/4" between of each side of the door and the shower kit when securing the door.





Order that pizza, you'll be done before it's here!

Attach the door to the first wall making sure to check that it is level. Install the braces in the corners and the brace above the door and you're done!

Where's that pizza?

Getting Out:



After the door is installed and the latch is in place, use an extra screw INSIDE the door to make sure your latch pull doesn't fall outside and lock you in!



For Finishing Touches + Accessories Installation  
See Page 10


# Deluxe Kit Installation Guide

## Deluxe Ingredients



### House Mount

- 3 Large Walls
- 2 Small Walls
- 1 Door
- 7 - 7' Cedar Posts
- Cedar Post Caps
- 2 Cedar Floors
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace



### Free Standing

- 5 Large Walls
- 2 Small Walls
- 1 Door
- 8 - 7' Cedar Posts
- Cedar Post Caps
- 2 Cedar Floors
- Cedar Corner Braces
- 1 Hardware Pack
- 1 Cedar Door Brace

#### CUSTOM TIP:

Doors can be rotated on any side you choose! Deluxe kits are set up for altering doors + walls.



# DELUXE INSTALLATION

## House Mount Double Unit

### Tools Needed:

Drill

Level

A good friend!

(L-Bracket for posts against house)



Using construction screws from the hardware pack, attach a cedar post to large wall. Make sure the rain cap is on top (wider board).

Add another cedar post to the other side of the large wall. Be sure both posts are aligned properly with each other. Do the same for another large wall attaching 1 post only.

Use a block or item to be referenced for height on all posts. We recommend 7".




Take your 2 large wall panels (one with 2 posts and one with 1 post) and drill them together.

Utilize the block that matches your desired kit height (from ground to bottom of the walls) as a staging piece when making the 90° connection.

**Important:** Make sure all panels are level throughout assembly!

*The arrow shows use of a block to aid with install of 2 large walls at the correct height.*



Always make sure inside of panels are flushed to inside of the post.

Again, make sure all panels are level!

Corner braces: Use these to make the kit square and to provide support. Screws are not part of the pack for braces but any old screw in the house will do.

# DELUXE INSTALLATION



Continue along attaching another post to another large wall and drill the walls together like the other side.



After the last large wall is installed, use the small walls to create the interior splash and privacy area. The small walls will be at a perpendicular angle to each other. Angle the construction screws for the small walls.



Install the door hardware:  
Install the hinges and hardware for the door first.

**For Finishing Touches +  
Accessories Installation  
See Page 10**

Install The door:  
Keep at least 1/4" space on both sides of the door for best use. Don't forget to install the door brace above the door opening for maximum stability.

Getting out: After the door is installed and the latch is in place, use an extra screw INSIDE the door to make sure your latch pull doesn't fall outside and lock you in!

# FINISHING TOUCHES + ACCESSORIES



## FLOORS & POST CAPS

Add floors and post caps to finish.

Post caps style:

Post caps can be set tight against the top or they can rest higher. It depends how far the post comes off the top of the walls.

We recommend 7" for the space under the bottom of walls to ground.

*NOTE: If you are in a windy area you may want to nail the post caps down.*



## BENCH INSTRUCTIONS:

**Step 1:** Locate the bench brackets and install them in the lower right and left corners of the large panel, sitting on top of the corner brackets. Be sure the angle cut on the bracket is toward the ground. Use (2) of the 4" construction lags to secure each bench bracket into the lower corners of the large panel. Lags will go through the panel frame and into the 4x4 support.

**Step 2:** Set the bench on top of the brackets. Secure the bench using the remaining (4) construction lags. Lags should be placed on either side of the top of the bench, fastening the bench into the brackets.

## PRIVACY SLAT ROOF

For maximum privacy out in the open, the slat roof still lets in plenty of light while giving you the privacy you want from higher floors, drones, and the NSA. For any questions go to the guides section on our website.



# Congrats!

That's it! Just add the finishing touches...and water!



TUTORIAL VIDEOS  
on Installation Page

